



Gleco Trap System

## CHANGING YOUR TRAP

Be sure to have a spare refill container ready at all times. Check the sediment level in your Gleco Trap weekly, and change the trap when residue accumulates to the fill line. Follow these steps to change out your Gleco Trap:

1. Drain the overflow into a new Gleco Trap bottle, and then close the drain valve.  
See Figure 1.
2. Remove the full bottle, close the lid, and discard. See Figure 2.
3. Apply a small amount of Vaseline to the top rim of the bottle, and then install the new bottle.  
See Figure 3.

**Note:** Rinsing two spoonfuls of granulated chlorine powder (available at any pool supply store) into your trap once per week will help maintain sanitary trap conditions.



Figure 1



Figure 2



Figure 3

## AVAILABLE REPLACEMENT BOTTLES

All replacement bottles are interchangeable among GT-19 and GT-64 Trap Systems. Contact your dealer to order replacement bottles.

- 10011** GT-19C 19 oz. Replacement Bottles - case of 6
- 10016** GT-32C 32 oz. Replacement Bottles - case of 12
- 10017** GT-43C 43 oz. Replacement Bottles - case of 6
- 10013** GT-64C 64 oz. Replacement Bottles - case of 6
- 10015** GT-128C 128 oz. Replacement Bottles - case of 4